

Heat Pressed Numbers or Letters

WARNING

WASHING/DRYING INSTRUCTIONS:

Garments with heat pressed (numbers or letters) should be “Turned Inside Out” before Washing & Drying.

1. Wash in COLD WATER on GENTLE CYCLE
2. Wash using NO Fabric Softener or Bleach
3. Machine Dry on COOL SETTING on GENTLE CYCLE

No warranty is provided by either the manufacturer or the applicator of heat pressed numbers or lettering.

Reattachment Procedures

Should any part of the heat pressing become loose or unattached from the garment. Lay the garment on a smooth flat surface (like an ironing board) with the heat pressing facing up. Smooth all the wrinkles out of the garment and if needed rearrange the loose or unattached heat pressed number or lettering back into its original position.

Lay a clean, dry cotton cloth over the garment and heat pressing. Place an iron set at 310 to 330 degrees (no steam) on the cloth which is covering the affected area and apply a 5 to 10 pound downward pressure and hold in place for 5 to 10 seconds over each affected area and repeat if necessary, taking care not to burn either the cover cloth or garment.